

TekTone® Tek-CARE®120+ System Layout

(Training is required to install and configure + systems. Maximum number of master stations, multicolor dome lights, and duty stations may be increased using the Tek-CARE Master Station Load Value Calculator available at www.tektone.com/resources. See installation manuals for complete wiring information.)

